

# ASSEMBLY INSTRUCTIONS

## PENDANT LAMP WOOD TOP




### PARTS INCLUDED

ITEM	DIAGRAM	DESCRIPTION	QTY
(A)		OUTLET BOX	1
(B)		HANGING BAR	1
(C)		SCREW	2
(D)		MOUNTING SCREW	2
(E)		LAMP SHADE	2

### INSTRUCTIONS

1. Unscrew the Hanging Bar (B) from the Canopy and attach it to ceiling Outlet box by using mounting screw (D), NOTE: DUE TO THE WEIGHT OF THIS ITEM, THE MINIMUM RATING ON YOUR CEILING OUTLET BOX MUST BE 100 LBS FOR FIXTURE.
2. Slide canopy up and screw tightly with the Hanging Bar (B) by using Screws (C) to hang the fixture to ceiling.
3. Pull wire from ceiling outlet box make proper electrical Connections with Wire Connector
4. Attach Hot wire (Red wire) from fixture to ground wire from outlet box tightly with the wire connector
5. Attach Neutral wire (Blue wire) from fixture to ground wire from outlet box tightly with the wire connector

### Mounting Assembly Instructions



### CARE INSTRUCTIONS:

- \*\* To clean, use a soft cloth only. DO NOT use any chemical or abrasive cleaner, \*\*